

Instructions for Applying Flip-Flop Paint – Spray

Three-step basecoat with Flip-Flop effect – spray application

Surface Preparation

The surface must be clean, free of rust, sanded, and degreased. The paint has no filling properties – any surface imperfections will be highlighted by the effect paint! To smooth the surface, use a filler and sand it smooth after drying (grit P400–800).

Step 1 – Black Basecoat

Use a matte black basecoat. Glossy surfaces are unsuitable – the effect paint won't adhere properly. A deep matte black base is essential for achieving the correct Flip-Flop effect. Allow to dry for at least 20 minutes – the surface must be dry to the touch.

Step 2 – Applying the Flip-Flop Effect Coat

Apply in thin layers from a distance of approx. 20–30 cm. Wait 5–10 minutes between coats. Apply 2–3 layers depending on the desired intensity. Use a cross-coat technique for even coverage. Let it dry for approximately 40 minutes before applying clear coat.

Step 3 – Clear Coat Application

To protect the paint and enhance the effect, apply a clear coat – gloss, satin or matte depending on your preference. We recommend a high-quality 2K clear coat. Apply according to the manufacturer's instructions.



Application Tips:

- Shake the spray can thoroughly before use, for at least 2 minutes.
- Work at a temperature of 20–25°C for the spray, surroundings, and object. Ensure good ventilation, no drafts, minimal dust in the air, and avoid direct sunlight.
- Keep the spray can upright during use to ensure proper spray pattern.
- **Always test the paint on a sample before application!**
- After use, turn the can upside down and briefly spray to clean the nozzle.
- Store at room temperature and protect from freezing or overheating.