

Instructions – Candy Pearl Paint in Spray Can

INSTRUCTIONS FOR USE – CANDY PEARL PAINT IN SPRAY CAN

Three-step Candy Pearl effect – spray can application

Solvent-based acrylic spray paint.

Surface Preparation

The surface must be clean, rust-free, sanded, degreased, and perfectly smooth. This paint has no filling properties, so scratches, filler marks, or sanding defects can remain visible through the final finish. Use a primer filler if needed and sand it smooth after drying (grit P400–800).

Step 1 – Black Basecoat

Shake the can well and apply 2–3 thin, even coats of matte black basecoat. Wait about 5–10 minutes between coats. The goal is a uniform, fully covered black surface without glossy spots. After the last coat, allow about 20 minutes until the surface is matte and dry to the touch.

Step 2 – Candy Pearl Effect Coat

Shake the can for at least 2 minutes and make a test spray first. Apply 2–3 thin to medium coats from 20–30 cm with about 70% overlap. Wait about 10 minutes between coats. Start and finish each spray pass outside the painted area.

Step 3 – Clear Topcoat

After the Candy Pearl coat has flashed off, apply a gloss clear topcoat. Gloss clear coat is essential for maximum effect, depth, and shine. For higher durability and UV protection, we recommend a high-quality 2K clear coat applied according to the manufacturer's instructions.



Application Tips:

- Apply at 18–25 °C in a dust-free, draught-free area, away from direct sun.
- Always keep the spray can in a vertical position during application to ensure an even spray pattern and prevent dripping from the nozzle.
- Clean the nozzle during application to avoid spitting.
- For multi-part projects, paint complete visible sides in one continuous process so the shade transitions evenly.
- **Always test on a sample surface first!**